



# VTR 1000

AUTOMOTIVE VOLTMETER  
INSTALLATION GUIDE

+12V  
(5 ~ 30V)



GND  
(Negative)

REMOTE

[www.taramps.com.br](http://www.taramps.com.br)

